Directed ELECTRONICS, INC.

Interface Module Application Guide
March 2007

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Acura	CL	1998	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	CL	1999	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	CL	2001	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	CL	2002	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	CL	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	Integra	2000	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	Integra	2001	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	MDX	2001	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	MDX	2002	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	MDX	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	MDX	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	MDX	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	MDX	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	NSX	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	NSX	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	NSX	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	NSX	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	NSX	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	NSX	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	NSX	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	NSX	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	NSX	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	RDX	2007	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Acura	RL	1996	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	RL	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Acura	RL	1998	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Acura	RL	1999	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Acura	RL	2000	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Acura	RL	2001	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Acura	RL	2002	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Acura	RL	2003	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Acura	RL	2004	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Acura	RL	2005	Immobilizer Bypass	Transponder	N/A					
Acura	RL	2006	Immobilizer Bypass	Transponder	N/A					
Acura	RSX	2002	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	RSX	2002	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	RSX	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	RSX	2003	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	RSX	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	RSX	2004	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	RSX	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	RSX	2005	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	RSX	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	1999	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	1999	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	TL	2000	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	2000	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	TL	2001	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	2001	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	TL	2002	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	2002	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	TL	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	2003	Door Lock Interface	Data Bus	IM-Honda-2					
Acura	TL	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	2004	Door Lock Interface	Data Bus	IM-Honda-3					
Acura	TL	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	2005	Door Lock Interface	Data Bus	IM-Honda-3					
Acura	TL	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TL	2006	Door Lock Interface	Data Bus	IM-Honda-3					
Acura	TSX	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TSX	2004	Door Lock Interface	Data Bus	IM-Honda-3					
Acura	TSX	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TSX	2005	Door Lock Interface	Data Bus	IM-Honda-3					
Acura	TSX	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Acura	TSX	2006	Door Lock Interface	Data Bus	IM-Honda-3					
Audi	A4	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A4	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A4	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A4	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A4	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A4	2004	Combo Interface	Data Bus	CAN1					
Audi	A6	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A6	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A6	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A6	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A6	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A6	2004	Combo Interface	Data Bus	CAN1					
Audi	A8	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A8	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A8	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	A8	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	Allroad	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	Allroad	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	Allroad	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	Allroad	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	S4	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	TT	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	TT	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	TT	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	TT	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Audi	TT	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	1995	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	1996	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	1997	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	1998	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	1999	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	2000	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	2001	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
BMW	3 Series	2002	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	2003	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	2004	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	3 Series	2005	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	1995	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	1996	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	1997	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	1998	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	1999	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	2000	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	2001	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	2002	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	5 Series	2003	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	7 Series	1995	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	7 Series	1996	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	7 Series	1997	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	7 Series	1998	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	7 Series	1999	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	7 Series	2000	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	7 Series	2001	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	8 Series	1995	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	8 Series	1996	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	8 Series	1997	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	8 Series	1998	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	X5	2001	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	X5	2002	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	X5	2003	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	Z3	1996	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	Z3	1997	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	Z3	1998	Immobilizer Bypass	EWS II	556UW				DesignTech 20402	DesignTech 29402
BMW	Z3	1999	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	Z3	2000	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	Z3	2001	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	Z3	2002	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	Z4	2003	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	Z4	2004	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
BMW	Z4	2005	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
Buick	Century	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	2000	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	2001	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	2002	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	2003	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	2004	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Century	2005	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LaCrosse	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Buick	LaCrosse	2005	Combo Interface	Data Bus	457GW					
Buick	LaCrosse	2005	Door Lock Interface	Data Bus	IM-GMSD-1					
Buick	LaCrosse	2006	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Buick	LaCrosse	2006	Combo Interface	Data Bus	457GW					
Buick	LaCrosse	2006	Door Lock Interface	Data Bus	IM-GMSD-1					
Buick	LeSabre	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LeSabre	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LeSabre	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LeSabre	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LeSabre	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LeSabre	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LeSabre	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LeSabre	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	LeSabre	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	LeSabre	2000	Combo Interface	Data Bus	1700G	457GW				
Buick	LeSabre	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	LeSabre	2001	Combo Interface	Data Bus	1700G	457GW				
Buick	LeSabre	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	LeSabre	2002	Combo Interface	Data Bus	1700G	457GW				
Buick	LeSabre	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	LeSabre	2003	Combo Interface	Data Bus	1700G	457GW				
Buick	LeSabre	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	LeSabre	2004	Combo Interface	Data Bus	1700G	457GW				
Buick	LeSabre	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	LeSabre	2005	Combo Interface	Data Bus	1700G	457GW				
Buick	Lucerne	2006	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1997	Immobilizer Bypass	PASS-Key III	555GW			556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1998	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	1999	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	2000	Combo Interface	Data Bus	457GW					
Buick	Park Avenue	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	2001	Combo Interface	Data Bus	457GW					
Buick	Park Avenue	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	2002	Combo Interface	Data Bus	457GW					
Buick	Park Avenue	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	2003	Combo Interface	Data Bus	457GW					
Buick	Park Avenue	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	2004	Combo Interface	Data Bus	457GW					
Buick	Park Avenue	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Park Avenue	2005	Combo Interface	Data Bus	457GW					
Buick	Rainier	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Buick	Rainier	2004	Combo Interface	Data Bus	1700G	457GW				
Buick	Rainier	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Buick	Rainier	2005	Combo Interface	Data Bus	1700G	457GW				
Buick	Rainier	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Buick	Rainier	2006	Combo Interface	Data Bus	1700G	457GW				
Buick	Reatta	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Reatta	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	2000	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	2001	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	2002	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	2003	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Regal	2004	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Rendezvous	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Rendezvous	2002	Combo Interface	Data Bus	1700G	457GW				
Buick	Rendezvous	2002	Door Lock Interface	Multiplex	456LW					
Buick	Rendezvous	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Rendezvous	2003	Combo Interface	Data Bus	1700G	457GW				
Buick	Rendezvous	2003	Door Lock Interface	Multiplex	456LW					
Buick	Rendezvous	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Rendezvous	2004	Combo Interface	Data Bus	1700G	457GW				
Buick	Rendezvous	2004	Door Lock Interface	Multiplex	456LW					
Buick	Rendezvous	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Rendezvous	2005	Combo Interface	Data Bus	1700G	457GW				
Buick	Rendezvous	2005	Door Lock Interface	Multiplex	456LW					
Buick	Rendezvous	2006	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Buick	Rendezvous	2006	Combo Interface	Data Bus	1700G	457GW				
Buick	Rendezvous	2006	Door Lock Interface	Multiplex	456LW					
Buick	Riviera	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Riviera	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Roadmaster	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Roadmaster	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Roadmaster	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Roadmaster	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Buick	Skylark	1996	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Buick	Skylark	1997	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Buick	Skylark	1998	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Buick	Terraza	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Buick	Terraza	2005	Combo Interface	Data Bus	1700G					
Buick	Terraza	2005	Door Lock Interface	Data Bus	IM-GMSD-1					
Buick	Terraza	2006	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Buick	Terraza	2006	Combo Interface	Data Bus	1700G					
Buick	Terraza	2006	Door Lock Interface	Data Bus	IM-GMSD-1					
Cadillac	Allante	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Allante	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Allante	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Brougham	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Brougham	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Brougham	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Brougham	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Brougham	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Catera	1997	Immobilizer Bypass	PASS-Key III	556UW				DesignTech 20402	DesignTech 29402
Cadillac	Catera	1998	Immobilizer Bypass	PASS-Key III	556UW				DesignTech 20402	DesignTech 29402
Cadillac	Catera	1999	Immobilizer Bypass	PASS-Key III	556UW				DesignTech 20402	DesignTech 29402
Cadillac	Catera	2000	Immobilizer Bypass	PASS-Key III	556UW				DesignTech 20402	DesignTech 29402
Cadillac	Catera	2001	Immobilizer Bypass	PASS-Key III	556UW				DesignTech 20402	DesignTech 29402
Cadillac	Concours	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Concours	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Concours	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Concours	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	CTS	2003	Immobilizer Bypass	PASS-Key III+	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	CTS	2003	Combo Interface	Data Bus	1700G	457GW				
Cadillac	CTS	2004	Immobilizer Bypass	PASS-Key III+	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	CTS	2004	Combo Interface	Data Bus	1700G	457GW				
Cadillac	CTS	2005	Immobilizer Bypass	PASS-Key III+	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	CTS	2005	Combo Interface	Data Bus	1700G	457GW				
Cadillac	CTS	2006	Immobilizer Bypass	PASS-Key III+	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	CTS	2006	Combo Interface	Data Bus	1700G	457GW				
Cadillac	De Ville	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	De Ville	2000	Immobilizer Bypass	PASS-Key III	555GW			556UW	DesignTech 20402	DesignTech 29402
Cadillac	De Ville	2000	Combo Interface	Data Bus	1700G	457GW				
Cadillac	De Ville	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	De Ville	2001	Combo Interface	Data Bus	1700G	457GW				
Cadillac	De Ville	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	De Ville	2002	Combo Interface	Data Bus	1700G	457GW				
Cadillac	De Ville	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	De Ville	2003	Combo Interface	Data Bus	1700G	457GW				
Cadillac	De Ville	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	De Ville	2004	Combo Interface	Data Bus	1700G	457GW				
Cadillac	De Ville	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	De Ville	2005	Combo Interface	Data Bus	1700G	457GW				
Cadillac	DTS	2006	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Cadillac	Eldorado	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	2000	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	2001	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Eldorado	2002	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Escalade	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade	1999	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade	2000	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade	2002	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade	2003	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade	2004	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade	2005	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade	2006	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade	2007	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Cadillac	Escalade ESV	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade ESV	2003	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade ESV	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade ESV	2004	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade ESV	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade ESV	2005	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade ESV	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade ESV	2006	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade Ext	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade Ext	2002	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade Ext	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade Ext	2003	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade Ext	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade Ext	2004	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade Ext	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade Ext	2005	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Escalade Ext	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Cadillac	Escalade Ext	2006	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Fleetwood	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Fleetwood	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Fleetwood	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Fleetwood	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Fleetwood	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Fleetwood	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Fleetwood	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Cadillac	Seville	1998	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	Seville	1999	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	Seville	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	Seville	2000	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Seville	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	Seville	2001	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Seville	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	Seville	2002	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Seville	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	Seville	2003	Combo Interface	Data Bus	1700G	457GW				
Cadillac	Seville	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Cadillac	Seville	2004	Combo Interface	Data Bus	1700G	457GW				
Cadillac	SRX	2004	Immobilizer Bypass	PASS-Key III+	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	SRX	2004	Combo Interface	Data Bus	1700G	457GW				
Cadillac	SRX	2005	Immobilizer Bypass	PASS-Key III+	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	SRX	2005	Combo Interface	Data Bus	1700G	457GW				
Cadillac	SRX	2006	Immobilizer Bypass	PASS-Key III+	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Cadillac	SRX	2006	Combo Interface	Data Bus	1700G	457GW				
Cadillac	STS	2005	Immobilizer Bypass	Immobilizer	N/A					
Cadillac	STS	2006	Immobilizer Bypass	Immobilizer	N/A					
Cadillac	XLR	2004	Immobilizer Bypass	Immobilizer	N/A					
Cadillac	XLR	2005	Immobilizer Bypass	Immobilizer	N/A					
Cadillac	XLR	2006	Immobilizer Bypass	Immobilizer	N/A					
Chevrolet	Astro	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Astro	1998	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Astro	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Astro	1999	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Astro	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Astro	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Astro	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Astro	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Astro	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Astro	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Astro	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Astro	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Astro	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Astro	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Astro	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Astro	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Avalanche	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Avalanche	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Avalanche	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Avalanche	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Avalanche	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Chevrolet	Avalanche	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Avalanche	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Avalanche	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Avalanche	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Avalanche	2006	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Avalanche	2007	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Chevrolet	Aveo	2004	Immobilizer Bypass	Transponder	1100F	1100X	OM-GMC-5	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Aveo	2005	Immobilizer Bypass	Transponder	1100F	1100X	OM-GMC-5	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Aveo	2006	Immobilizer Bypass	Transponder	1100F	1100X	OM-GMC-5	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	1998	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Blazer	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	1999	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Blazer	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Blazer	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Blazer	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Blazer	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Blazer	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Blazer	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Blazer	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Camaro	1986	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1987	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1988	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1989	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	2000	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	2001	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Camaro	2002	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Caprice	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Caprice	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Caprice	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Caprice	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	1995	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	1996	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	1997	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	1998	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	1999	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Cavalier	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Cavalier	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Cavalier	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Cavalier	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Cavalier	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Cavalier	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Cobalt	2005	Immobilizer Bypass	Passlock	N/A					
Chevrolet	Cobalt	2005	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Cobalt	2006	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Cobalt	2006	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Colorado	2004	Immobilizer Bypass	Passlock	N/A					
Chevrolet	Colorado	2005	Immobilizer Bypass	Passlock	N/A					
Chevrolet	Colorado	2006	Immobilizer Bypass	Passlock	N/A					
Chevrolet	Corvette	1984	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1985	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1986	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1987	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1988	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1989	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	2000	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	2001	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	2002	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	2003	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	2004	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Corvette	2005	Immobilizer Bypass	Immobilizer	N/A					
Chevrolet	Corvette	2006	Immobilizer Bypass	Immobilizer	N/A					
Chevrolet	Equinox	2005	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Equinox	2006	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	1998	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Express Van	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	1999	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Express Van	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Express Van	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	2001	Combo Interface	Data Bus	1700G	457GW				

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Chevrolet	Express Van	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Express Van	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Express Van	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Express Van	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Express Van	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Express Van	2006	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Full Size Pickup	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Full Size Pickup	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Full Size Pickup	1999	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Full Size Pickup	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Full Size Pickup	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Full Size Pickup	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Full Size Pickup	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Full Size Pickup	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Full Size Pickup	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Full Size Pickup	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Full Size Pickup	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Full Size Pickup	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Full Size Pickup	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Full Size Pickup	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Full Size Pickup	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	HHR	2006	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Chevrolet	HHR	2006	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Impala	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Impala	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Impala	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Impala	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Impala	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Impala	2000	Door Lock Interface	Multiplex	456LW					
Chevrolet	Impala	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Impala	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Impala	2001	Door Lock Interface	Multiplex	456LW					
Chevrolet	Impala	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Impala	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Impala	2002	Door Lock Interface	Multiplex	456LW					
Chevrolet	Impala	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Impala	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Impala	2003	Door Lock Interface	Multiplex	456LW					
Chevrolet	Impala	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Impala	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Impala	2004	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Impala	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Impala	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Impala	2005	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Impala	2006	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Chevrolet	Lumina	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Lumina	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Lumina	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Lumina	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Lumina	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Lumina	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Lumina	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Lumina	2000	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	1997	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	1997	Combo Interface	Data Bus	1700G					
Chevrolet	Malibu	1998	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	1998	Combo Interface	Data Bus	1700G					
Chevrolet	Malibu	1999	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	1999	Combo Interface	Data Bus	1700G					
Chevrolet	Malibu	2000	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	2000	Combo Interface	Data Bus	1700G					
Chevrolet	Malibu	2001	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	2001	Combo Interface	Data Bus	1700G					
Chevrolet	Malibu	2001	Door Lock Interface	Multiplex	456LW					
Chevrolet	Malibu	2002	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	2002	Combo Interface	Data Bus	1700G					
Chevrolet	Malibu	2002	Door Lock Interface	Multiplex	456LW					
Chevrolet	Malibu	2003	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	2003	Combo Interface	Data Bus	1700G					
Chevrolet	Malibu	2003	Door Lock Interface	Multiplex	456LW					
Chevrolet	Malibu	2004	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	2004	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Malibu	2005	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	2005	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Malibu	2006	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Malibu	2006	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Malibu Maxx	2004	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Malibu Maxx	2004	Door Lock Interface	Multiplex	456LW					
Chevrolet	Malibu Maxx	2005	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Chevrolet	Malibu Maxx	2005	Door Lock Interface	Multiplex	456LW					
Chevrolet	Malibu Maxx	2006	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Chevrolet	Malibu Maxx	2006	Door Lock Interface	Multiplex	456LW					
Chevrolet	Monte Carlo	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Monte Carlo	2000	Door Lock Interface	Multiplex	456LW					
Chevrolet	Monte Carlo	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Monte Carlo	2001	Door Lock Interface	Multiplex	456LW					
Chevrolet	Monte Carlo	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Monte Carlo	2002	Door Lock Interface	Multiplex	456LW					
Chevrolet	Monte Carlo	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Monte Carlo	2003	Door Lock Interface	Multiplex	456LW					

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Chevrolet	Monte Carlo	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Monte Carlo	2004	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Monte Carlo	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Monte Carlo	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Monte Carlo	2005	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Chevrolet	Monte Carlo	2006	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Chevrolet	S-10 Pickup	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	S-10 Pickup	1998	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	S-10 Pickup	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	S-10 Pickup	1999	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	S-10 Pickup	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	S-10 Pickup	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	S-10 Pickup	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	S-10 Pickup	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	S-10 Pickup	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	S-10 Pickup	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	S-10 Pickup	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	S-10 Pickup	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	S-10 Pickup	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	S-10 Pickup	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Silverado	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Silverado	1999	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Silverado	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Silverado	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Silverado	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Silverado	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Silverado	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Silverado	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Silverado	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Silverado	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Silverado	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Silverado	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Silverado	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Silverado	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Silverado	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Silverado	2006	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	SSR	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	SSR	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	SSR	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	SSR	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	1999	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Suburban	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Suburban	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Suburban	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Suburban	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Suburban	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Suburban	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Suburban	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Suburban	2006	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Suburban	2007	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	1999	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Tahoe	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Tahoe	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Tahoe	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Tahoe	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Tahoe	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Tahoe	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Tahoe	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Tahoe	2006	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Tahoe	2007	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
Chevrolet	Trailblazer	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Trailblazer	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Trailblazer	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Trailblazer	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Trailblazer	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Trailblazer	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Trailblazer	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Trailblazer	2005	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Trailblazer	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Chevrolet	Trailblazer	2006	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Uplander	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Uplander	2005	Combo Interface	Data Bus	1700G					
Chevrolet	Uplander	2005	Door Lock Interface	Data Bus	IM-GMSD-1					
Chevrolet	Uplander	2006	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Uplander	2006	Combo Interface	Data Bus	1700G					
Chevrolet	Uplander	2006	Door Lock Interface	Data Bus	IM-GMSD-1					
Chevrolet	Venture	1999	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Venture	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Venture	2000	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Venture	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Venture	2001	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Venture	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Venture	2002	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Venture	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Venture	2003	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Venture	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Chevrolet	Venture	2004	Combo Interface	Data Bus	1700G	457GW				
Chevrolet	Venture	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Chevrolet	Venture	2005	Combo Interface	Data Bus	1700G	457GW				
Chrysler	300	2005	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	300	2005	Combo Interface	Data Bus	IOM-Chrysler-7					
Chrysler	300	2005	Door Lock Interface	Multiplex	456LW					
Chrysler	300	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	300	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Chrysler	300	2006	Door Lock Interface	Multiplex	456LW					
Chrysler	300M	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	300M	1999	Door Lock Interface	Multiplex	456LW					
Chrysler	300M	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	300M	2000	Door Lock Interface	Multiplex	456LW					
Chrysler	300M	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	300M	2001	Door Lock Interface	Multiplex	456LW					
Chrysler	300M	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	300M	2002	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	300M	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	300M	2003	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	300M	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	300M	2004	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Cirrus	1995	Door Lock Interface	Multiplex	456LW					
Chrysler	Cirrus	1996	Door Lock Interface	Multiplex	456LW					
Chrysler	Cirrus	1997	Door Lock Interface	Multiplex	456LW					
Chrysler	Cirrus	1998	Door Lock Interface	Multiplex	456LW					
Chrysler	Cirrus	1999	Door Lock Interface	Multiplex	456LW					
Chrysler	Cirrus	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Cirrus	2000	Door Lock Interface	Multiplex	456LW					
Chrysler	Concorde	1998	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Concorde	1998	Door Lock Interface	Multiplex	456LW					
Chrysler	Concorde	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Concorde	1999	Door Lock Interface	Multiplex	456LW					
Chrysler	Concorde	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Concorde	2000	Door Lock Interface	Multiplex	456LW					
Chrysler	Concorde	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Concorde	2001	Door Lock Interface	Multiplex	456LW					
Chrysler	Concorde	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Concorde	2002	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Concorde	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Concorde	2003	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Concorde	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Concorde	2004	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Crossfire	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Chrysler	Crossfire	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Chrysler	LHS	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	LHS	1999	Door Lock Interface	Multiplex	456LW					
Chrysler	LHS	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	LHS	2000	Door Lock Interface	Multiplex	456LW					
Chrysler	LHS	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	LHS	2001	Door Lock Interface	Multiplex	456LW					
Chrysler	Pacifica	2004	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Pacifica	2004	Combo Interface	Data Bus	IOM-Chrysler-6					
Chrysler	Pacifica	2004	Door Lock Interface	Multiplex	456LW					
Chrysler	Pacifica	2005	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Pacifica	2005	Combo Interface	Data Bus	IOM-Chrysler-6					
Chrysler	Pacifica	2005	Door Lock Interface	Multiplex	456LW					
Chrysler	Pacifica	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Pacifica	2006	Combo Interface	Data Bus	IOM-Chrysler-6					
Chrysler	Pacifica	2006	Door Lock Interface	Multiplex	456LW					
Chrysler	Prowler	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Prowler	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	PT Cruiser	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	PT Cruiser	2001	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	PT Cruiser	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	PT Cruiser	2002	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	PT Cruiser	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	PT Cruiser	2003	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	PT Cruiser	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	PT Cruiser	2004	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	PT Cruiser	2005	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	PT Cruiser	2005	Door Lock Interface	Multiplex	456LW					
Chrysler	PT Cruiser	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	PT Cruiser	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Chrysler	PT Cruiser	2006	Door Lock Interface	Multiplex	456LW					
Chrysler	Sebring Convertible	1996	Door Lock Interface	Multiplex	456LW					
Chrysler	Sebring Convertible	1997	Door Lock Interface	Multiplex	456LW					
Chrysler	Sebring Convertible	1998	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	1998	Door Lock Interface	Multiplex	456LW					
Chrysler	Sebring Convertible	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	1999	Door Lock Interface	Multiplex	456LW					
Chrysler	Sebring Convertible	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	2000	Door Lock Interface	Multiplex	456LW					
Chrysler	Sebring Convertible	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	2001	Door Lock Interface	Multiplex	456LW					
Chrysler	Sebring Convertible	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	2002	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Sebring Convertible	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	2003	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Sebring Convertible	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	2004	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Sebring Convertible	2005	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	2005	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Sebring Convertible	2006	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Convertible	2006	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Sebring Coupe	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Chrysler	Sebring Coupe	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Chrysler	Sebring Coupe	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Chrysler	Sebring Coupe	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Chrysler	Sebring Coupe	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Chrysler	Sebring Sedan	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Sedan	2001	Door Lock Interface	Multiplex	456LW					
Chrysler	Sebring Sedan	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Sedan	2002	Door Lock Interface	Data Bus	457CW	456LW				

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Chrysler	Sebring Sedan	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Sedan	2003	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Sebring Sedan	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Sedan	2004	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Sebring Sedan	2005	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Sedan	2005	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Sebring Sedan	2006	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Sebring Sedan	2006	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Town and Country	1996	Door Lock Interface	Multiplex	456LW					
Chrysler	Town and Country	1997	Door Lock Interface	Multiplex	456LW					
Chrysler	Town and Country	1998	Door Lock Interface	Multiplex	456LW					
Chrysler	Town and Country	1999	Door Lock Interface	Multiplex	456LW					
Chrysler	Town and Country	2000	Door Lock Interface	Multiplex	456LW					
Chrysler	Town and Country	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Town and Country	2001	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Town and Country	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Town and Country	2002	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Town and Country	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Town and Country	2003	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Town and Country	2004	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Town and Country	2004	Combo Interface	Data Bus	IOM-Chrysler-6					
Chrysler	Town and Country	2004	Door Lock Interface	Multiplex	456LW					
Chrysler	Town and Country	2005	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Town and Country	2005	Combo Interface	Data Bus	IOM-Chrysler-6					
Chrysler	Town and Country	2005	Door Lock Interface	Multiplex	456LW					
Chrysler	Town and Country	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Town and Country	2006	Combo Interface	Data Bus	IOM-Chrysler-6					
Chrysler	Town and Country	2006	Door Lock Interface	Multiplex	456LW					
Chrysler	Voyager	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Voyager	2001	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Voyager	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Voyager	2002	Door Lock Interface	Data Bus	457CW	456LW				
Chrysler	Voyager	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Chrysler	Voyager	2003	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Caliber	2007	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Caliber	2007	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Caliber	2007	Door Lock Interface	Multiplex	456LW					
Dodge	Caravan	1996	Door Lock Interface	Multiplex	456LW					
Dodge	Caravan	1997	Door Lock Interface	Multiplex	456LW					
Dodge	Caravan	1998	Door Lock Interface	Multiplex	456LW					
Dodge	Caravan	1999	Door Lock Interface	Multiplex	456LW					
Dodge	Caravan	2000	Door Lock Interface	Multiplex	456LW					
Dodge	Caravan	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Caravan	2001	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Caravan	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Caravan	2002	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Caravan	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Caravan	2003	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Caravan	2004	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Caravan	2004	Combo Interface	Data Bus	IOM-Chrysler-6					
Dodge	Caravan	2004	Door Lock Interface	Multiplex	456LW					
Dodge	Caravan	2005	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Caravan	2005	Combo Interface	Data Bus	IOM-Chrysler-6					
Dodge	Caravan	2005	Door Lock Interface	Multiplex	456LW					
Dodge	Caravan	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Caravan	2006	Combo Interface	Data Bus	IOM-Chrysler-6					
Dodge	Caravan	2006	Door Lock Interface	Multiplex	456LW					
Dodge	Charger	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Charger	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Charger	2006	Door Lock Interface	Multiplex	456LW					
Dodge	Dakota pickup	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Dakota pickup	2001	Door Lock Interface	Multiplex	456LW					
Dodge	Dakota pickup	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Dakota pickup	2002	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Dakota pickup	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Dakota pickup	2003	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Dakota pickup	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Dakota pickup	2004	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Dakota pickup	2005	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Dakota pickup	2005	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Dakota pickup	2005	Door Lock Interface	Multiplex	456LW					
Dodge	Dakota pickup	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Dakota pickup	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Dakota pickup	2006	Door Lock Interface	Multiplex	456LW					
Dodge	Durango	2000	Door Lock Interface	Multiplex	456LW					
Dodge	Durango	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Durango	2001	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Durango	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Durango	2002	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Durango	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Durango	2003	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Durango	2004	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Dodge	Durango	2004	Door Lock Interface	Multiplex	456LW					
Dodge	Durango	2005	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Dodge	Durango	2005	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Durango	2005	Door Lock Interface	Multiplex	456LW					
Dodge	Durango	2006	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Dodge	Durango	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Durango	2006	Door Lock Interface	Multiplex	456LW					
Dodge	Intrepid	1998	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Intrepid	1998	Door Lock Interface	Multiplex	456LW					
Dodge	Intrepid	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Intrepid	1999	Door Lock Interface	Multiplex	456LW					
Dodge	Intrepid	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Intrepid	2000	Door Lock Interface	Multiplex	456LW					
Dodge	Intrepid	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Intrepid	2001	Door Lock Interface	Multiplex	456LW					
Dodge	Intrepid	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Intrepid	2002	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Intrepid	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Intrepid	2003	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Intrepid	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Intrepid	2004	Door Lock Interface	Data Bus	457CW	456LW				

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Dodge	Magnum	2005	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Magnum	2005	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Magnum	2005	Door Lock Interface	Multiplex	456LW					
Dodge	Magnum	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Magnum	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Magnum	2006	Door Lock Interface	Multiplex	456LW					
Dodge	Neon	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Neon	2000	Door Lock Interface	Multiplex	456LW					
Dodge	Neon	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Neon	2001	Door Lock Interface	Multiplex	456LW					
Dodge	Neon	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Neon	2002	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Neon	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Neon	2003	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Neon	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Neon	2004	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Neon	2005	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Neon	2005	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Ram Pickup	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Ram Pickup	2002	Door Lock Interface	Multiplex	456LW					
Dodge	Ram Pickup	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Ram Pickup	2003	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Ram Pickup	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Ram Pickup	2004	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Ram Pickup	2005	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Ram Pickup	2005	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Ram Pickup	2006	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Dodge	Ram Pickup	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Dodge	Ram Pickup	2006	Door Lock Interface	Multiplex	456LW					
Dodge	Sprinter	2003	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Dodge	Sprinter	2004	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Dodge	Sprinter	2005	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Dodge	Sprinter	2006	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Dodge	Stratus	1995	Door Lock Interface	Multiplex	456LW					
Dodge	Stratus	1996	Door Lock Interface	Multiplex	456LW					
Dodge	Stratus	1997	Door Lock Interface	Multiplex	456LW					
Dodge	Stratus	1998	Door Lock Interface	Multiplex	456LW					
Dodge	Stratus	1999	Door Lock Interface	Multiplex	456LW					
Dodge	Stratus	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Stratus	2000	Door Lock Interface	Multiplex	456LW					
Dodge	Stratus Coupe	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Dodge	Stratus Coupe	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Dodge	Stratus Coupe	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Dodge	Stratus Coupe	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Dodge	Stratus Coupe	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Dodge	Stratus Sedan	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Stratus Sedan	2001	Door Lock Interface	Multiplex	456LW					
Dodge	Stratus Sedan	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Stratus Sedan	2002	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Stratus Sedan	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Stratus Sedan	2003	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Stratus Sedan	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Stratus Sedan	2004	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Stratus Sedan	2005	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Stratus Sedan	2005	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Stratus Sedan	2006	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Dodge	Stratus Sedan	2006	Door Lock Interface	Data Bus	457CW	456LW				
Dodge	Viper SRT/10	2003	Door Lock Interface	Multiplex	456LW					
Dodge	Viper SRT/10	2004	Door Lock Interface	Multiplex	456LW					
Dodge	Viper SRT/10	2005	Door Lock Interface	Multiplex	456LW					
Ford	Contour	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Contour	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Contour	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Crown Victoria	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Edge	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Escape	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Escape	2001	Door Lock Interface	Multiplex	456LW					
Ford	Escape	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Escape	2002	Door Lock Interface	Multiplex	456LW					
Ford	Escape	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Escape	2003	Door Lock Interface	Multiplex	456LW					
Ford	Escape	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Escape	2004	Door Lock Interface	Multiplex	456LW					
Ford	Escape	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Escape	2005	Door Lock Interface	Multiplex	456LW					
Ford	Escape	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Escape	2006	Door Lock Interface	Multiplex	456LW					
Ford	Escape	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Escape	2007	Door Lock Interface	Multiplex	456LW					
Ford	Excursion	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Excursion	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Excursion	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Excursion	2003	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Excursion	2004	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Excursion	2005	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	1997	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	1998	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Ford	Expedition	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Expedition	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	1995	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	1996	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	1997	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer Sport	2002	Immobilizer Bypass	SecuriLock	556SW			556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer Sport	2003	Immobilizer Bypass	SecuriLock	556SW			556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer Sport Trac	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer Sport Trac	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer Sport Trac	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer Sport Trac	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer Sport Trac	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Explorer Sport Trac	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	1997	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	1998	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	2003	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	F Series Light Duty	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Five Hundred	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Five Hundred	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Five Hundred	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Focus	2000	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Focus	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Focus	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Focus	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Focus	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Focus	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Focus	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Focus	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Freestar	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Freestar	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Freestar	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Freestar	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Freestyle	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Freestyle	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Freestyle	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Fusion	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Fusion	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	GT	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	GT	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	1996	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	1997	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	2003	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	2004	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Mustang	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Probe	1989	Door Lock Interface	Multiplex	456LW					
Ford	Probe	1990	Door Lock Interface	Multiplex	456LW					
Ford	Probe	1991	Door Lock Interface	Multiplex	456LW					
Ford	Probe	1992	Door Lock Interface	Multiplex	456LW					
Ford	Probe	1993	Door Lock Interface	Multiplex	456LW					
Ford	Probe	1994	Door Lock Interface	Multiplex	456LW					
Ford	Probe	1995	Door Lock Interface	Multiplex	456LW					
Ford	Probe	1996	Door Lock Interface	Multiplex	456LW					
Ford	Probe	1997	Door Lock Interface	Multiplex	456LW					
Ford	Ranger	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Ranger	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Ranger	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Ranger	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Ranger	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Ranger	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Ranger	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Ranger	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Ranger	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	1996	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	1997	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	2000	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Taurus	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Thunderbird	2002	Immobilizer Bypass	SecuriLock	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Ford	Thunderbird	2003	Immobilizer Bypass	SecuriLock	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Ford	Thunderbird	2004	Immobilizer Bypass	SecuriLock	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Ford	Thunderbird	2005	Immobilizer Bypass	SecuriLock	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Ford	Windstar	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Ford	Windstar	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Ford	Windstar	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Windstar	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Ford	Windstar	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
GMC	Canyon	2004	Immobilizer Bypass	Passlock	N/A					
GMC	Canyon	2005	Immobilizer Bypass	Passlock	N/A					
GMC	Canyon	2006	Immobilizer Bypass	Passlock	N/A					
GMC	Denali	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Denali	1999	Combo Interface	Data Bus	1700G	457GW				
GMC	Denali	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Denali	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Denali	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Denali	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy	1999	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy	2002	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy	2006	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy XL	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy XL	2002	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy XL	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy XL	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy XL	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy XL	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy XL	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy XL	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy XL	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy XL	2006	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy XUV	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy XUV	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Envoy XUV	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Envoy XUV	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Full Size Pickup	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Full Size Pickup	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Full Size Pickup	1999	Combo Interface	Data Bus	1700G	457GW				
GMC	Full Size Pickup	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Full Size Pickup	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Full Size Pickup	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Full Size Pickup	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Full Size Pickup	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Full Size Pickup	2002	Combo Interface	Data Bus	1700G	457GW				
GMC	Full Size Pickup	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Full Size Pickup	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Full Size Pickup	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Full Size Pickup	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Full Size Pickup	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Full Size Pickup	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Jimmy	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Jimmy	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Jimmy	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Jimmy	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	1998	Combo Interface	Data Bus	1700G	457GW				
GMC	Safari	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	1999	Combo Interface	Data Bus	1700G	457GW				
GMC	Safari	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Safari	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Safari	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	2002	Combo Interface	Data Bus	1700G	457GW				
GMC	Safari	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Safari	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Safari	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Safari	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	1998	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	1999	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	2002	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Savana Van	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Savana Van	2006	Combo Interface	Data Bus	1700G	457GW				
GMC	Sierra	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sierra	1999	Combo Interface	Data Bus	1700G	457GW				
GMC	Sierra	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sierra	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Sierra	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sierra	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Sierra	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sierra	2002	Combo Interface	Data Bus	1700G	457GW				

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
GMC	Sierra	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sierra	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Sierra	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sierra	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Sierra	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sierra	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Sierra	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sierra	2006	Combo Interface	Data Bus	1700G	457GW				
GMC	Sonoma	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sonoma	1998	Combo Interface	Data Bus	1700G	457GW				
GMC	Sonoma	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sonoma	1999	Combo Interface	Data Bus	1700G	457GW				
GMC	Sonoma	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sonoma	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Sonoma	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sonoma	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Sonoma	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sonoma	2002	Combo Interface	Data Bus	1700G	457GW				
GMC	Sonoma	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sonoma	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Sonoma	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Sonoma	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Suburban	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Suburban	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	1999	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	2002	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon	2006	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon	2007	Immobilizer Bypass	PASS-Key III+	556UW				DesignTech 20402	DesignTech 29402
GMC	Yukon XL	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon XL	2000	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon XL	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon XL	2001	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon XL	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon XL	2002	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon XL	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon XL	2003	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon XL	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon XL	2004	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon XL	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon XL	2005	Combo Interface	Data Bus	1700G	457GW				
GMC	Yukon XL	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
GMC	Yukon XL	2006	Combo Interface	Data Bus	1700G	457GW				
Honda	Accord	1998	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	1998	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Accord	1999	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	1999	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Accord	2000	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	2000	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Accord	2001	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	2001	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Accord	2002	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	2002	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Accord	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	2003	Door Lock Interface	Data Bus	IM-Honda-3					
Honda	Accord	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	2004	Door Lock Interface	Data Bus	IM-Honda-3					
Honda	Accord	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	2005	Door Lock Interface	Data Bus	IM-Honda-3					
Honda	Accord	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Accord	2006	Door Lock Interface	Data Bus	IM-Honda-3					
Honda	Accord Hybrid	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	Accord Hybrid	2005	Door Lock Interface	Data Bus	IM-Honda-3					
Honda	Civic	2001	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Civic	2001	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Civic	2002	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Civic	2002	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Civic	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Civic	2003	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Civic	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Civic	2004	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Civic	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Civic	2005	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Civic	2006	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Honda	CR-V	2002	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	CR-V	2002	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	CR-V	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	CR-V	2003	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	CR-V	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	CR-V	2004	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	CR-V	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	CR-V	2005	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	CR-V	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	CR-V	2006	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	CR-V	2007	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Honda	Element	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Element	2003	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Element	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Element	2004	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Element	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Honda	Element	2005	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Element	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Element	2006	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Fit	2007	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Insight	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	Insight	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	Insight	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	Insight	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	Insight	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	Insight	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	Insight	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	Odyssey	1998	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	1998	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Odyssey	1999	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	1999	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Odyssey	2000	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	2000	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Odyssey	2001	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	2001	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Odyssey	2002	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	2002	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Odyssey	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	2003	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Odyssey	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	2004	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Odyssey	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	2005	Door Lock Interface	Data Bus	IM-Honda-3					
Honda	Odyssey	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Odyssey	2006	Door Lock Interface	Data Bus	IM-Honda-3					
Honda	Pilot	2003	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Pilot	2003	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Pilot	2004	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Pilot	2004	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Pilot	2005	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Pilot	2005	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Pilot	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Pilot	2006	Door Lock Interface	Data Bus	IM-Honda-2					
Honda	Prelude	1997	Immobilizer Bypass	Transponder	1100F	1100X	555DW	556UW	DesignTech 20402	DesignTech 29402
Honda	Prelude	1998	Immobilizer Bypass	Transponder	1100F	1100X	555DW	556UW	DesignTech 20402	DesignTech 29402
Honda	Prelude	1999	Immobilizer Bypass	Transponder	1100F	1100X	555DW	556UW	DesignTech 20402	DesignTech 29402
Honda	Prelude	2000	Immobilizer Bypass	Transponder	1100F	1100X	555DW	556UW	DesignTech 20402	DesignTech 29402
Honda	Prelude	2001	Immobilizer Bypass	Transponder	1100F	1100X	555DW	556UW	DesignTech 20402	DesignTech 29402
Honda	Ridgeline	2006	Immobilizer Bypass	Transponder	1100F	1100X	556HW	556UW	DesignTech 20402	DesignTech 29402
Honda	Ridgeline	2006	Door Lock Interface	Data Bus	IM-Honda-3					
Honda	S2000	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	S2000	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	S2000	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	S2000	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	S2000	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	S2000	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Honda	S2000	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hummer	H2	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Hummer	H2	2003	Combo Interface	Data Bus	1700G	457GW				
Hummer	H2	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Hummer	H2	2004	Combo Interface	Data Bus	1700G	457GW				
Hummer	H2	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Hummer	H2	2005	Combo Interface	Data Bus	1700G	457GW				
Hummer	H2	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Hummer	H2	2006	Combo Interface	Data Bus	1700G	457GW				
Hummer	H3	2006	Immobilizer Bypass	Passlock	N/A					
Hyundai	Accent	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Accent	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Azera	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Elantra	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Elantra	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Elantra	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Elantra	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Elantra	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Elantra	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Elantra	2007	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Entourage	2007	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Entourage	2007	Door Lock Interface	Data Bus	IM-Kia-1					
Hyundai	Santa Fe	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Santa Fe	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Santa Fe	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Santa Fe	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Santa Fe	2007	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Sonata	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Sonata	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Sonata	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Hyundai	Tiburon	2003	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Hyundai	Tiburon	2004	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Hyundai	Tiburon	2005	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Hyundai	Tiburon	2006	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Hyundai	Tucson	2005	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Hyundai	Tucson	2006	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Hyundai	XG300	2001	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Hyundai	XG350	2002	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Hyundai	XG350	2003	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Hyundai	XG350	2004	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Hyundai	XG350	2005	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Infiniti	FX35/FX45	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	FX35/FX45	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	FX35/FX45	2004	Door Lock Interface	Data Bus	IM-Nissan-1					
Infiniti	FX35/FX45	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	FX35/FX45	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Infiniti	G20	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	G20	2001	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Infiniti	G20	2002	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Infiniti	G35 Coupe	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	G35 Coupe	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	G35 Coupe	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	G35 Sedan	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Infiniti	G35 Sedan	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	G35 Sedan	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	I30	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	I30	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	I30	2001	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Infiniti	I35	2002	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Infiniti	I35	2003	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Infiniti	I35	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	M35/M45	2006	Immobilizer Bypass	Transponder	N/A					
Infiniti	M35/M45	2006	Door Lock Interface	Data Bus	IM-Nissan-1					
Infiniti	M45	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	M45	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	Q45	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	Q45	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	Q45	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	Q45	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	Q45	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	Q45	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	Q45	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	Q45	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	QX4	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	QX4	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	QX4	2001	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Infiniti	QX4	2002	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Infiniti	QX4	2003	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Infiniti	QX56	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	QX56	2004	Door Lock Interface	Data Bus	IM-Nissan-1					
Infiniti	QX56	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Infiniti	QX56	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Isuzu	Ascender	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Isuzu	Ascender	2003	Combo Interface	Data Bus	1700G					
Isuzu	Ascender	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Isuzu	Ascender	2004	Combo Interface	Data Bus	1700G					
Isuzu	Ascender	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Isuzu	Ascender	2005	Combo Interface	Data Bus	1700G					
Isuzu	Ascender	2006	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Isuzu	Ascender	2006	Combo Interface	Data Bus	1700G					
Isuzu	Axiom	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Isuzu	Axiom	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Isuzu	Hombre	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Isuzu	Hombre	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Isuzu	Hombre	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Isuzu	i-280	2006	Immobilizer Bypass	Passlock	N/A					
Isuzu	i-350	2006	Immobilizer Bypass	Passlock	N/A					
Isuzu	Rodeo	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Isuzu	Rodeo	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Isuzu	Rodeo Sport	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	S-type	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	S-type	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	S-type	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	S-type	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	S-type	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	S-type	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJ Series	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJ Series	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJ8	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJ8	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJ8	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJ8	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJ8	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJ8	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJR	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJR	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJR	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJR	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJR	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XJR	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XK Series	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XK Series	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XK8	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XK8	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XK8	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XK8	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XK8	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XK8	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XKR	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XKR	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XKR	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	XKR	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	X-type	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	X-type	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	X-type	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jaguar	X-type	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Jeep	Cherokee	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Cherokee	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Cherokee	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Commander	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Commander	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Jeep	Commander	2006	Door Lock Interface	Multiplex	456LW					
Jeep	Grand Cherokee	1996	Door Lock Interface	Data Bus	455TW					
Jeep	Grand Cherokee	1997	Door Lock Interface	Data Bus	455TW					
Jeep	Grand Cherokee	1998	Door Lock Interface	Data Bus	455TW					
Jeep	Grand Cherokee	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	1999	Door Lock Interface	Data Bus	455JW					
Jeep	Grand Cherokee	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2000	Door Lock Interface	Data Bus	455JW					
Jeep	Grand Cherokee	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2001	Door Lock Interface	Data Bus	455JW					
Jeep	Grand Cherokee	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2002	Door Lock Interface	Data Bus	455JW					
Jeep	Grand Cherokee	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2003	Door Lock Interface	Data Bus	455JW					
Jeep	Grand Cherokee	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Jeep	Grand Cherokee	2004	Door Lock Interface	Data Bus	455JW					
Jeep	Grand Cherokee	2005	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2005	Combo Interface	Data Bus	IOM-Chrysler-7					
Jeep	Grand Cherokee	2005	Door Lock Interface	Multiplex	456LW					
Jeep	Grand Cherokee	2006	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Grand Cherokee	2006	Combo Interface	Data Bus	IOM-Chrysler-7					
Jeep	Grand Cherokee	2006	Door Lock Interface	Multiplex	456LW					
Jeep	Liberty	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Liberty	2002	Door Lock Interface	Data Bus	457CW	456LW				
Jeep	Liberty	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Liberty	2003	Door Lock Interface	Data Bus	457CW	456LW				
Jeep	Liberty	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Liberty	2004	Door Lock Interface	Data Bus	457CW	456LW				
Jeep	Liberty	2005	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Liberty	2005	Combo Interface	Data Bus	IOM-Chrysler-6					
Jeep	Liberty	2005	Door Lock Interface	Multiplex	456LW					
Jeep	Wrangler	1998	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2002	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2003	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2004	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2005	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2006	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2007	Immobilizer Bypass	Sentry Key	556CW			556UW	DesignTech 20402	DesignTech 29402
Jeep	Wrangler	2007	Door Lock Interface	Multiplex	456LW					
Kia	Amanti	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Kia	Amanti	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Kia	Amanti	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Kia	Optima	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Kia	Optima	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Kia	Sedona	2004	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Kia	Sedona	2005	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Kia	Sedona	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Kia	Sedona	2006	Door Lock Interface	Data Bus	IM-Kia-1					
Kia	Sorento	2004	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Kia	Sorento	2005	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Kia	Spectra (2.0L)	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Kia	Spectra (2.0L)	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Kia	Sportage	2005	Immobilizer Bypass	Transponder	1100F	1100X	OM-Hyundai-1	556UW	DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Discovery Series II	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Freelander	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Freelander	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Freelander	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Freelander	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	LR3	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2003	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2004	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
Land Rover	Range Rover	2005	Immobilizer Bypass	EWS III	556UW				DesignTech 20402	DesignTech 29402
Lexus	ES 300	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 300	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 330	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 330	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	ES 330	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	ES 330	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2004	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	GS 300	2005	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 300	2006	Immobilizer Bypass	Transponder	N/A					
Lexus	GS 400	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 400	1998	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	GS 400	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 400	1999	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	GS 400	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 400	2000	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	GS 430	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2004	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	GS 430	2005	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	GS 430	2006	Immobilizer Bypass	Transponder	N/A					
Lexus	GX 470	2003	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	GX 470	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	GX 470	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	GX 470	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	GX 470	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 250	2006	Immobilizer Bypass	Transponder	N/A					
Lexus	IS 300	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 300	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 300	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 300	2004	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 300	2005	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	IS 350	2006	Immobilizer Bypass	Transponder	N/A					

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Lexus	LS 400	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Lexus	LS 400	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 400	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 400	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 430	2001	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 430	2001	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	LS 430	2002	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 430	2002	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	LS 430	2003	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 430	2003	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	LS 430	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 430	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	LS 430	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LS 430	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2003	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	LX 470	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	LX 470	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	1998	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 300	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	1999	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 300	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	2000	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 300	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	2001	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 300	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	2002	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 300	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 300	2003	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 330	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 330	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 330	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 330	2005	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 330	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	RX 330	2006	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	RX 400h	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 300	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 300	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 300	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 400	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 400	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 400	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 430	2002	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 430	2003	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 430	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 430	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Lexus	SC 430	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lexus	SC 430	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Lincoln	Aviator	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Aviator	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Aviator	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Blackwood	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Continental	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2000	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	LS	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Mark LT	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Mark LT	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Mark VIII	1997	Immobilizer Bypass	SecuriLock	556UW				DesignTech 20402	DesignTech 29402
Lincoln	Mark VIII	1998	Immobilizer Bypass	SecuriLock	556UW				DesignTech 20402	DesignTech 29402
Lincoln	MKX	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	MKZ	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	1998	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Navigator	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Town Car	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Lincoln	Zephyr	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	3	2004	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	3	2004	Door Lock Interface	Multiplex	456LW					
Mazda	3	2005	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	3	2005	Door Lock Interface	Multiplex	456LW					
Mazda	3	2006	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Mazda	3	2006	Door Lock Interface	Multiplex	456LW					
Mazda	5	2006	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	5	2006	Door Lock Interface	Multiplex	456LW					
Mazda	6	2003	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	6	2003	Door Lock Interface	Multiplex	456LW					
Mazda	6	2004	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	6	2004	Door Lock Interface	Multiplex	456LW					
Mazda	6	2005	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	6	2005	Door Lock Interface	Multiplex	456LW					
Mazda	6	2006	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	6	2006	Door Lock Interface	Multiplex	456LW					
Mazda	626	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	626	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	626	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	626	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	626	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	B 2500, B 3000, B 4000	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B 2500, B 3000, B 4000	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	B Series	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	CX-7	2007	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	CX-7	2007	Door Lock Interface	Multiplex	456LW					
Mazda	Miata	2001	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	Miata	2001	Door Lock Interface	Multiplex	456LW					
Mazda	Miata	2002	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	Miata	2002	Door Lock Interface	Multiplex	456LW					
Mazda	Miata	2003	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	Miata	2003	Door Lock Interface	Multiplex	456LW					
Mazda	Miata	2004	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	Miata	2004	Door Lock Interface	Multiplex	456LW					
Mazda	Miata	2005	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	Miata	2005	Door Lock Interface	Multiplex	456LW					
Mazda	Miata	2006	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	Miata	2006	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	1994	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	1995	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	1996	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	1997	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	Millenia	1998	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	Millenia	1999	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	Millenia	2000	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	Millenia	2001	Door Lock Interface	Multiplex	456LW					
Mazda	Millenia	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	Millenia	2002	Door Lock Interface	Multiplex	456LW					
Mazda	MPV	2000	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	MPV	2000	Door Lock Interface	Multiplex	456LW					
Mazda	MPV	2001	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	MPV	2001	Door Lock Interface	Multiplex	456LW					
Mazda	MPV	2002	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	MPV	2002	Door Lock Interface	Multiplex	456LW					
Mazda	MPV	2003	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	MPV	2003	Door Lock Interface	Multiplex	456LW					
Mazda	MPV	2004	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	MPV	2004	Door Lock Interface	Multiplex	456LW					
Mazda	MPV	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	MPV	2005	Door Lock Interface	Multiplex	456LW					
Mazda	MPV	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mazda	MPV	2006	Door Lock Interface	Multiplex	456LW					
Mazda	Protege	1997	Door Lock Interface	Multiplex	456LW					
Mazda	Protege	1998	Door Lock Interface	Multiplex	456LW					
Mazda	Protege	1999	Door Lock Interface	Multiplex	456LW					
Mazda	Protege	2000	Door Lock Interface	Multiplex	456LW					
Mazda	Protege	2001	Door Lock Interface	Multiplex	456LW					
Mazda	Protege	2002	Door Lock Interface	Multiplex	456LW					
Mazda	Protege	2003	Door Lock Interface	Multiplex	456LW					
Mazda	Protege5	2002	Door Lock Interface	Multiplex	456LW					
Mazda	Protege5	2003	Door Lock Interface	Multiplex	456LW					
Mazda	RX-8	2004	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	RX-8	2004	Door Lock Interface	Multiplex	456LW					
Mazda	RX-8	2005	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	RX-8	2005	Door Lock Interface	Multiplex	456LW					
Mazda	RX-8	2006	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Mazda	RX-8	2006	Door Lock Interface	Multiplex	456LW					
Mazda	Tribute	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2001	Door Lock Interface	Multiplex	456LW					
Mazda	Tribute	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2002	Door Lock Interface	Multiplex	456LW					
Mazda	Tribute	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2003	Door Lock Interface	Multiplex	456LW					
Mazda	Tribute	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	555SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2004	Door Lock Interface	Multiplex	456LW					
Mazda	Tribute	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2005	Door Lock Interface	Multiplex	456LW					
Mazda	Tribute	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mazda	Tribute	2006	Door Lock Interface	Multiplex	456LW					
Mercedes Benz	C 230	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	C 230	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	C 230	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	C 280	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	C 280	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	C 280	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	C Class	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	C Class	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	CL Class	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	CL Class	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Mercedes Benz	CLK Class	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	2001	Door Lock Interface	Multiplex	456LW					
Mercedes Benz	CLK Class	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	CLK Class	2002	Door Lock Interface	Multiplex	456LW					
Mercedes Benz	E Class	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	E Class	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 320	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 320	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 320	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 430	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	ML 430	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	ML Class	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	ML Class	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	ML Class	2006	Immobilizer Bypass	Transponder	N/A					
Mercedes Benz	ML Class	2006	Door Lock Interface	Multiplex	456LW					
Mercedes Benz	S 320	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	S 420	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	S 500	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	2000	Door Lock Interface	Multiplex	456LW					
Mercedes Benz	S Class	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	2001	Door Lock Interface	Multiplex	456LW					
Mercedes Benz	S Class	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	S Class	2002	Door Lock Interface	Multiplex	456LW					
Mercedes Benz	SL Class	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	SL Class	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercedes Benz	SLK Class	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mercury	Cougar	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Cougar	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Cougar	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Cougar	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2001	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2002	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Grand Marquis	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Marauder	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Marauder	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mariner	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mariner	2005	Door Lock Interface	Multiplex	456LW					
Mercury	Mariner	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mariner	2006	Door Lock Interface	Multiplex	456LW					
Mercury	Mariner	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mariner	2007	Door Lock Interface	Multiplex	456LW					
Mercury	Milan	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Milan	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Montego	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Montego	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Montego	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Monterey	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Monterey	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Monterey	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Monterey	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	1997	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2006	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mountaineer	2007	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mystique	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mystique	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Mystique	2000	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	1996	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	1997	Immobilizer Bypass	PATS	555FW			556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	1998	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	1999	Immobilizer Bypass	PATS	1100F	1100X	555PW/555FW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2000	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2001	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2002	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2003	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2004	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mercury	Sable	2005	Immobilizer Bypass	SecuriLock	1100F	1100X	556SW	556UW	DesignTech 20402	DesignTech 29402
Mini	Cooper	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mini	Cooper	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mini	Cooper	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mini	Cooper	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Diamante	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Mitsubishi	Diamante	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Eclipse	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Endeavor	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Endeavor	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Galant	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Lancer	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Lancer	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Lancer	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Montero Sport	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Outlander	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Outlander	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Raider	2006	Immobilizer Bypass	Sentry Key	556UW				DesignTech 20402	DesignTech 29402
Mitsubishi	Raider	2006	Door Lock Interface	Multiplex	456LW					
Nissan	350Z	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	350Z	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	350Z	2004	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	350Z	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	350Z	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	350Z	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	350Z	2006	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Altima	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Altima	2001	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Altima	2002	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Altima	2003	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Altima	2004	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Altima	2004	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Altima	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Altima	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Altima	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Altima	2006	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Altima	2007	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Armada	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Armada	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Armada	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Armada	2006	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Armada	2007	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Armada	2007	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Frontier	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Frontier	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Frontier	2007	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Maxima	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Maxima	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Maxima	2001	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Maxima	2002	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Maxima	2002	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Maxima	2003	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Maxima	2003	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Maxima	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Maxima	2004	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Maxima	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Maxima	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Maxima	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Maxima	2006	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Murano	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Murano	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Murano	2004	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Murano	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Murano	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Pathfinder	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2001	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2002	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2003	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2004	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Pathfinder	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Pathfinder Armada	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Pathfinder Armada	2004	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Quest	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Quest	2004	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Quest	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Quest	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Sentra	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Sentra	2001	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Sentra	2002	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Sentra	2003	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Sentra	2004	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Sentra	2005	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Sentra	2006	Immobilizer Bypass	Transponder	1100F	1100X	OM-Nissan-1	556UW	DesignTech 20402	DesignTech 29402
Nissan	Titan	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Titan	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Titan	2005	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Titan	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Nissan	Titan	2006	Door Lock Interface	Data Bus	IM-Nissan-1					
Nissan	Versa	2007	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Xterra	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Nissan	Xterra	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Oldsmobile	Achieva	1996	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Oldsmobile	Achieva	1997	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Oldsmobile	Achieva	1998	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	1999	Door Lock Interface	Multiplex	456LW					
Oldsmobile	Alero	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2000	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Alero	2000	Door Lock Interface	Multiplex	456LW					
Oldsmobile	Alero	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2001	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Alero	2001	Door Lock Interface	Multiplex	456LW					
Oldsmobile	Alero	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2002	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Alero	2002	Door Lock Interface	Multiplex	456LW					
Oldsmobile	Alero	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2003	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Alero	2003	Door Lock Interface	Multiplex	456LW					
Oldsmobile	Alero	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Alero	2004	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Alero	2004	Door Lock Interface	Multiplex	456LW					
Oldsmobile	Aurora	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	2001	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Aurora	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	2002	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Aurora	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Aurora	2003	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Bravada	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	1999	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Bravada	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2000	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Bravada	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2001	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Bravada	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2002	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Bravada	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2003	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Bravada	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Bravada	2004	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Cutlass	1997	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass	1998	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass	1999	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Ciera	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Ciera	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Supreme	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Supreme	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Cutlass Supreme	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight LSS	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Eighty-Eight LSS	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	1998	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	1998	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Intrigue	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	1999	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Intrigue	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	2000	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Intrigue	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	2001	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Intrigue	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Oldsmobile	Intrigue	2002	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Ninety-Eight	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Ninety-Eight	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Regency	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Regency	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	1999	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2000	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Silhouette	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2001	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Silhouette	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2002	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Silhouette	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2003	Combo Interface	Data Bus	1700G	457GW				
Oldsmobile	Silhouette	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Oldsmobile	Silhouette	2004	Combo Interface	Data Bus	1700G	457GW				
Plymouth	Breeze	1996	Door Lock Interface	Multiplex	456LW					
Plymouth	Breeze	1997	Door Lock Interface	Multiplex	456LW					
Plymouth	Breeze	1998	Door Lock Interface	Multiplex	456LW					
Plymouth	Breeze	1999	Door Lock Interface	Multiplex	456LW					
Plymouth	Breeze	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Plymouth	Breeze	2000	Door Lock Interface	Multiplex	456LW					
Plymouth	Neon	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Plymouth	Neon	2000	Door Lock Interface	Multiplex	456LW					
Plymouth	Neon	2001	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Plymouth	Neon	2001	Door Lock Interface	Multiplex	456LW					
Plymouth	Prowler	1999	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402
Plymouth	Prowler	2000	Immobilizer Bypass	Sentry Key	555CW			556UW	DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Plymouth	Voyager	1996	Door Lock Interface	Multiplex	456LW					
Plymouth	Voyager	1997	Door Lock Interface	Multiplex	456LW					
Plymouth	Voyager	1998	Door Lock Interface	Multiplex	456LW					
Plymouth	Voyager	1999	Door Lock Interface	Multiplex	456LW					
Plymouth	Voyager	2000	Door Lock Interface	Multiplex	456LW					
Pontiac	Aztek	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Aztek	2001	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Aztek	2001	Door Lock Interface	Multiplex	456LW					
Pontiac	Aztek	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Aztek	2002	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Aztek	2002	Door Lock Interface	Multiplex	456LW					
Pontiac	Aztek	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Aztek	2003	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Aztek	2003	Door Lock Interface	Multiplex	456LW					
Pontiac	Aztek	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Aztek	2004	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Aztek	2004	Door Lock Interface	Multiplex	456LW					
Pontiac	Aztek	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Aztek	2005	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Aztek	2005	Door Lock Interface	Multiplex	456LW					
Pontiac	Bonneville	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	2000	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Bonneville	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	2001	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Bonneville	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	2002	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Bonneville	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	2003	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Bonneville	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	2004	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Bonneville	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Bonneville	2005	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Firebird	1986	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1987	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1988	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1989	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1990	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1991	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1992	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1993	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1997	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1998	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	1999	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	2000	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	2001	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Firebird	2002	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	G6	2005	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Pontiac	G6	2005	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Pontiac	G6	2006	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Pontiac	G6	2006	Door Lock Interface	Data Bus	IM-GMSD-1	456LW				
Pontiac	Grand Am	1996	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	1997	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	1998	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	1999	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	1999	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Grand Am	1999	Door Lock Interface	Multiplex	456LW					
Pontiac	Grand Am	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	2000	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Grand Am	2000	Door Lock Interface	Multiplex	456LW					
Pontiac	Grand Am	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	2001	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Grand Am	2001	Door Lock Interface	Multiplex	456LW					
Pontiac	Grand Am	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	2002	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Grand Am	2002	Door Lock Interface	Multiplex	456LW					
Pontiac	Grand Am	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	2003	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Grand Am	2003	Door Lock Interface	Multiplex	456LW					
Pontiac	Grand Am	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	2004	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Grand Am	2004	Door Lock Interface	Multiplex	456LW					
Pontiac	Grand Am	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Am	2005	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Grand Am	2005	Door Lock Interface	Multiplex	456LW					
Pontiac	Grand Prix	1994	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	1995	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	1996	Immobilizer Bypass	VATS	652T resistor pack				DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	2004	Immobilizer Bypass	PASS-Key III	556UW				DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	2004	Door Lock Interface	Data Bus	IM-GMSD-1					
Pontiac	Grand Prix	2005	Immobilizer Bypass	PASS-Key III	556UW				DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	2005	Combo Interface	Data Bus	1700G					
Pontiac	Grand Prix	2005	Door Lock Interface	Data Bus	IM-GMSD-1					
Pontiac	Grand Prix	2006	Immobilizer Bypass	PASS-Key III	556UW				DesignTech 20402	DesignTech 29402
Pontiac	Grand Prix	2006	Combo Interface	Data Bus	1700G					
Pontiac	Grand Prix	2006	Door Lock Interface	Data Bus	IM-GMSD-1					
Pontiac	GTO	2004	Immobilizer Bypass	Immobilizer	N/A					
Pontiac	GTO	2005	Immobilizer Bypass	Immobilizer	N/A					
Pontiac	GTO	2006	Immobilizer Bypass	Immobilizer	N/A					

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Pontiac	Montana	1999	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana	2000	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Montana	2001	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana	2001	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Montana	2002	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana	2002	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Montana	2003	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana	2003	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Montana	2004	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana	2004	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Montana	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana	2005	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Montana SV6	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana SV6	2005	Combo Interface	Data Bus	1700G					
Pontiac	Montana SV6	2005	Door Lock Interface	Data Bus	IM-GMSD-1					
Pontiac	Montana SV6	2006	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Pontiac	Montana SV6	2006	Combo Interface	Data Bus	1700G					
Pontiac	Montana SV6	2006	Door Lock Interface	Data Bus	IM-GMSD-1					
Pontiac	Solstice	2006	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	1995	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	1996	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	1997	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	1998	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	1999	Immobilizer Bypass	Passlock I	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	2000	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Sunfire	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	2001	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Sunfire	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	2002	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Sunfire	2003	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	2003	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Sunfire	2004	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	2004	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Sunfire	2005	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Pontiac	Sunfire	2005	Combo Interface	Data Bus	1700G	457GW				
Pontiac	Torrent	2006	Immobilizer Bypass	Passlock II	556LW	555LW			DesignTech 20402	DesignTech 29402
Pontiac	Transport	1999	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Transport	2000	Immobilizer Bypass	PASS-Key III	1100F	1100X	555GW	556UW	DesignTech 20402	DesignTech 29402
Pontiac	Transport	2000	Combo Interface	Data Bus	457GW					
Porsche	911 Carrera 993	1995	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 993	1996	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 993	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 993	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 996	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 996	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 996	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 996	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 996	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	911 Carrera 996	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	Boxster	1997	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	Boxster	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	Boxster	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	Boxster	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	Boxster	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	Boxster	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	Boxster	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Porsche	Boxster	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-3	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-3	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-3	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-3	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-3	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-3	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-5	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-5	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-5	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-5	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-5	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-5	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Saab	9-7X	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Saturn	Ion	2003	Immobilizer Bypass	Passlock	N/A					
Saturn	Ion	2003	Door Lock Interface	Multiplex	456LW					
Saturn	Ion	2004	Immobilizer Bypass	Passlock	N/A					
Saturn	Ion	2004	Door Lock Interface	Multiplex	456LW					
Saturn	Ion	2005	Immobilizer Bypass	Passlock	N/A					
Saturn	Ion	2005	Door Lock Interface	Multiplex	456LW					
Saturn	Ion	2006	Immobilizer Bypass	Passlock	N/A					
Saturn	Ion	2006	Door Lock Interface	Multiplex	456LW					
Saturn	L-Series	2000	Immobilizer Bypass	Passlock II	N/A					
Saturn	L-Series	2001	Immobilizer Bypass	Passlock II	N/A					
Saturn	L-Series	2002	Immobilizer Bypass	Passlock II	N/A					
Saturn	L-Series	2003	Immobilizer Bypass	Passlock II	N/A					
Saturn	L-Series	2004	Immobilizer Bypass	Passlock II	N/A					
Saturn	L-Series	2005	Immobilizer Bypass	Passlock II	N/A					
Saturn	Relay	2005	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Saturn	Relay	2005	Combo Interface	Data Bus	1700G					
Saturn	Relay	2005	Door Lock Interface	Data Bus	IM-GMSD-1					
Saturn	Relay	2006	Immobilizer Bypass	PASS-Key III	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Saturn	Relay	2006	Combo Interface	Data Bus	1700G					
Saturn	Relay	2006	Door Lock Interface	Data Bus	IM-GMSD-1					
Saturn	S-Series	2000	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Saturn	S-Series	2000	Combo Interface	Data Bus	1700G	457GW				
Saturn	S-Series	2001	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Saturn	S-Series	2001	Combo Interface	Data Bus	1700G	457GW				
Saturn	S-Series	2002	Immobilizer Bypass	Passlock II	1100F	1100X	556LW	555LW	DesignTech 20402	DesignTech 29402
Saturn	S-Series	2002	Combo Interface	Data Bus	1700G	457GW				
Saturn	Sky	2007	Immobilizer Bypass	PASS-Key III+	OM-GMC-6			556UW	DesignTech 20402	DesignTech 29402
Saturn	Vue	2002	Immobilizer Bypass	Passlock II	N/A					
Saturn	Vue	2003	Immobilizer Bypass	Passlock II	N/A					
Saturn	Vue	2004	Immobilizer Bypass	Passlock II	N/A					
Saturn	Vue	2005	Immobilizer Bypass	Passlock II	N/A					

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Saturn	Vue	2006	Immobilizer Bypass	Passlock II	N/A					
Scion	tC	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Scion	tC	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	B9 Tribeca	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	Forester	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	Forester	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	Impreza	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	Impreza	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	Legacy	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	Legacy	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	Outback	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Subaru	Outback	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Suzuki	Grand Vitara	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Suzuki	Verona	2004	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Suzuki	Verona	2005	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Suzuki	Verona	2006	Immobilizer Bypass	Transponder	1100F	1100X		556UW	DesignTech 20402	DesignTech 29402
Toyota	4Runner	1999	Immobilizer Bypass	Transponder	1100X	555XW		556UW	DesignTech 20402	DesignTech 29402
Toyota	4Runner	2000	Immobilizer Bypass	Transponder	1100X	555XW		556UW	DesignTech 20402	DesignTech 29402
Toyota	4Runner	2001	Immobilizer Bypass	Transponder	1100X	555XW		556UW	DesignTech 20402	DesignTech 29402
Toyota	4Runner	2002	Immobilizer Bypass	Transponder	1100X	555XW		556UW	DesignTech 20402	DesignTech 29402
Toyota	4Runner	2003	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	4Runner	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	4Runner	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	4Runner	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	2000	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Avalon	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	2001	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Avalon	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	2002	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Avalon	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	2003	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Avalon	2004	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Avalon	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Avalon	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	2004	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Camry	2007	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	Corolla	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Corolla	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Highlander	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Highlander	2001	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Highlander	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Highlander	2002	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Highlander	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Highlander	2003	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Highlander	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Highlander	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Highlander	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Highlander	2005	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Highlander	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Highlander	2006	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Highlander Hybrid	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	1998	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	2003	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	2003	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Land Cruiser	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Land Cruiser	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Land Cruiser	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Matrix	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Matrix	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	MR2	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	MR2	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	MR2	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	MR2	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	MR2	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	MR2	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	Prius	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	Prius	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	Prius	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	Prius	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	Prius	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Prius	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	Prius	2006	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Toyota	RAV4	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	RAV4	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	RAV4	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	RAV4	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	RAV4	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	RAV4	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Sequoia	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Sequoia	2001	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Sequoia	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Sequoia	2002	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Sequoia	2003	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Sequoia	2003	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Sequoia	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Sequoia	2004	Door Lock Interface	Data Bus	IM-Toyota-2					

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Toyota	Sequoia	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Sequoia	2005	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Sequoia	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Sequoia	2006	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Sienna	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Sienna	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Sienna	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Sienna	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Sienna	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Sienna	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Sienna	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Sienna	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Solara	1999	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Solara	2000	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Solara	2001	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Solara	2002	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Solara	2003	Immobilizer Bypass	Transponder	1100X	1100F	555XW	556UW	DesignTech 20402	DesignTech 29402
Toyota	Solara	2004	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Solara	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Solara	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Tacoma	2005	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Tacoma	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Tundra Double Cab	2004	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Tundra Double Cab	2005	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Tundra Double Cab	2006	Door Lock Interface	Data Bus	IM-Toyota-2					
Toyota	Yaris	2006	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Toyota	Yaris	2007	Immobilizer Bypass	Transponder	1100X	1100F		556UW	DesignTech 20402	DesignTech 29402
Volkswagen	Beetle	1998	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Beetle	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Beetle	1999	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Beetle	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Beetle	2000	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Beetle	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Beetle	2001	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Beetle	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Beetle	2002	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Beetle	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Beetle	2003	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Beetle	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Beetle	2004	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Cabrio	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Cabrio	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Cabrio	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Eurovan	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Eurovan	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Eurovan	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/ power windows	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/ power windows	2000	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/ power windows	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/ power windows	2001	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/ power windows	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/ power windows	2002	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/ power windows	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/ power windows	2003	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/ power windows	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/ power windows	2004	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/o power windows	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/o power windows	2000	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/o power windows	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/o power windows	2001	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/o power windows	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/o power windows	2002	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/o power windows	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/o power windows	2003	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Golf w/o power windows	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Golf w/o power windows	2004	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	GTI w/ power windows	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/ power windows	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/ power windows	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/ power windows	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/ power windows	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/o power windows	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/o power windows	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/o power windows	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/o power windows	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	GTI w/o power windows	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta V	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta V	2005	Combo Interface	Data Bus	CAN1					
Volkswagen	Jetta w/ power windows	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/ power windows	2000	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/ power windows	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/ power windows	2001	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/ power windows	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/ power windows	2002	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/ power windows	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/ power windows	2003	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/ power windows	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/ power windows	2004	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/o power window	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/o power window	2000	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/o power window	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/o power window	2001	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/o power window	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/o power window	2002	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/o power window	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/o power window	2003	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Jetta w/o power window	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Jetta w/o power window	2004	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Passat	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Passat	2000	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Passat	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Passat	2001	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Passat	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402

Make	Model	Year	Category	Type	Part Number	Alternate Part 1	Alternate Part 2	Alternate Part 3	Alternate Part 4	Alternate Part 5
Volkswagen	Passat	2002	Door Lock Interface	Data Bus	IM-Volkswagen-1					
Volkswagen	Passat	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volkswagen	Passat	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	C70	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	C70	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	C70	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	C70	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	C70	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	C70	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	C70	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S40	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S40	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S40	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S40	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S40	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S40	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S60	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S60	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S60	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S60	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S70	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S70	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S70	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S80	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S80	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S80	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S80	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S80	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S80	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S90	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	S90	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V40	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V40	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V40	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V40	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V40	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V50	2005	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V70	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V70	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V70	2000	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V70	2001	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V70	2002	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V70	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V70	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V90	1998	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	V90	1999	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	XC70	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	XC70	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	XC90	2003	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402
Volvo	XC90	2004	Immobilizer Bypass	Transponder	556UW				DesignTech 20402	DesignTech 29402